








3-PIN CONNECTOR SOCKET (NEMA) QUL-ACC-NEM-133
 5-PIN CONNECTOR SOCKET (NEMA) QUL-ACC-NEM-135
 7-PIN CONNECTOR SOCKET (NEMA) QUL-ACC-NEM-137




QUL-XXX-W-XXX-XXX







QUL-ACC-RFM-142



-  x1
-  x1
-  x2
-  x2
-  x2




QUL-ACC-RFM-143



QUL-ACC-RFM-144



SIM CARD INSTALLING



<p>1. OPEN</p> <p>The diagram shows the SIM card cover with the top flap lifted upwards. The internal components, including a battery, a small square chip, and a SIM card slot, are visible.</p>	<p>2. INSTAL SIM CARD</p> <p>The diagram shows the SIM card being inserted into the slot. The card is held in place by a small metal spring mechanism.</p>	<p>3. CLOSE</p> <p>The diagram shows the SIM card cover with the top flap closed, covering the internal components.</p>
---	--	---

